



Husky PolyBack Oil Filter Pan Dripulator Chart

Use this guide to calculate how often you need to change out your Husky Polyback Oil Filter Pan.

Drips/Minute	Gallons/Month	Basic Husky Pan	Large Husky Pan	2x4 Super Husky Pan	4x4 Super Husky Pan
1	.6	18 weeks	33 weeks	54 weeks	107 weeks*
5	2.9	4 weeks	7 weeks	12 weeks	24 weeks
10	5.5	2 weeks	3-4 weeks	6 weeks	12 weeks
30	16.5	NA	NA	2 weeks	4 weeks

It's a "Bleeder"

*Guaranteed for two years or until saturated.

HOW TO USE THESE NUMBERS

- 1) Grab a stopwatch or use your phone.
- 2) Select the oil leak you want to measure.
- 3) Count the number of drops per minute.

Based on the number of drops per minute, use the table above to gauge how long until filter pad change out.

Note: These numbers push the liner and filter pads to the limit. We recommend changing the filter pads before the liner starts to get saturated.



Reusable: Husky Oil Filter Pads are like a sponge. They can be squeezed out and reused up to 20 times. Be sure to dispose of or recycle used oil in compliance with all regulations.



Warning: The speed of drips will vary with seasonal temperatures. The best practice is to check once every 90 days.



Grabs oil. Lets clean rainwater through.



To protect the Husky Filter Liner, please change Filter Pads before they become fully saturated.